

Benito™

1000W ELECTRIC IRON

• Fast • Powerful • Convenient



Smart Kitchen Appliances

THANK YOU

FOR CHOOSING BENITO

Crafted for Modern Indian Kitchens

Welcome to the Benito family. We're delighted to be a part of your everyday garment care experience.

Your Benito Iron is thoughtfully designed to deliver fast heating, smooth performance, and reliable durability for effortless ironing every day.

Built to match modern household needs, Benito combines efficiency, comfort, and style to make ironing quicker, easier, and more convenient.

Here's to crisp clothes and confident moments every single day — the Benito way.

Happy Cooking!

WARRANTY CARD

Warranty Terms & Conditions

Benito Iron 1000 Watts comes with a 2 Year Warranty against manufacturing defects from the date of purchase.

Warranty becomes void if the product is opened, tampered with, misused, or not used as per instructions.

Please keep the warranty card and purchase proof for service claims.

Only authorized service centers are allowed to repair the appliance.

Not Covered Under Warranty

- Power Cord & Plug
- Plastic Body Parts
- Handle & Knob
- Indicator Light
- Soleplate Coating
- External Damage & Wear Tear

Damage caused due to mishandling, overheating, water exposure, or unauthorized repairs is not covered under warranty.

Sr. No _____ Tested by _____ Remarks _____

Purchase's Name & Address : _____

Date of Purchase _____ Cash Memo No _____

IMPORTANT

Safety Instructions

Please read all instructions carefully before using the Benito Iron 1000 Watts.

- Keep the iron away from water, moisture, and direct heat sources.
- Do not touch the hot soleplate during or immediately after use.
- Ensure the temperature control knob is set correctly before operation.
- Keep the appliance away from children.
- Always unplug the iron before cleaning or storing.
- Do not leave the iron switched on unattended for long durations.
- Use the appliance only for ironing clothes and fabrics.
- Do not immerse the iron, cord, or plug in water.
- Allow the iron to cool completely before storing.

Safety Reminder

Always operate the Benito Iron on a flat, stable, and heat-resistant surface.

Design Style :

- Warning Icons
- Light Grey Background Sections
- Premium Red Highlight Accents for Caution Notes

FEATURE HIGHLIGHTS

Benito™

ELECTRIC DRY IRON

Smooth ironing. Effortless every day.

FEATURE HIGHLIGHTS



Non-Stick Soleplate

Glides smoothly over all fabrics



Adjustable Temperature Control

Perfect settings for different fabrics



Safe & Reliable

Overheating protection for worry-free use




Flexible Power Cord

360° swivel for easy movement



Ideal for Cotton, Linen, Synthetics & more



1000W Power



Durable Design



Easy to Use

HOW TO USE

Operating Instructions

Benito™ IRON



Place the iron upright on a flat and stable surface.



Plug the power cord into a suitable electrical outlet.



Turn the temperature control knob to the desired fabric setting:
Nylon → Silk → Wool → Cotton → Linen



Allow the iron to heat for a few moments until the indicator light turns off or stabilizes.



Begin ironing with smooth and gentle strokes.



For delicate fabrics, use a lower temperature setting to avoid damage.



After use, turn the temperature knob to the "OFF" position.



Unplug the iron from the power supply.



Allow the iron to cool completely before storing.



Store the iron upright in a dry and safe place.

PRODUCT SPECIFICATIONS

• Power Consumption	1000 Watts
• Voltage	220-240V AC
• Manufacturer Warranty	2 years
• Soleplate Type	Non-Stick Coated Soleplate
• Indicator Light	Yes
• Handle Type	Ergonomic Cool Touch Handle
• Cord Type	Flexible Swivel Power Cord
• Heating Element	Fast Heating Technology
• Body Material	Durable Heat Resistant Plastic
• Safety Feature	Overheat Protection
• Suitable Fabrics	Nylon, Silk, Wool, Cotton & Linen
• Design	Lightweight & Compact

DO'S

READ INSTRUCTIONS CAREFULLY.

- Always place the iron on a stable, heat-resistant surface before use.
- Check the temperature control knob and select the correct fabric setting before ironing.
- Allow the iron to heat properly before starting to iron clothes.
- Use smooth and gentle movements while ironing for better fabric care and wrinkle removal.
- Keep the power cord away from the hot soleplate during operation.
- Unplug the iron after use and allow it to cool completely before storing.
- Clean the soleplate regularly with a soft cloth after the iron has cooled down.
- Keep the appliance away from water and moisture to avoid electric shock.
- Store the iron in an upright position in a dry and safe place.
- In case of malfunction, contact an authorized service center with your warranty card.

DON'T'S

READ INSTRUCTIONS CAREFULLY.

- Do not leave the iron unattended while it is switched on or plugged in.
- Do not touch the hot soleplate during or immediately after use.
- Do not iron wet clothes unless the fabric instructions specifically allow it.
- Do not use the iron with damaged cords, plugs, or loose electrical connections.
- Do not immerse the iron, cord, or plug in water or any other liquid.
- Do not wrap the power cord tightly around the iron while it is still hot.
- Do not allow children to operate or play with the appliance.
- Do not use abrasive cleaners or sharp objects to clean the soleplate.
- Do not place the hot iron directly on delicate surfaces or fabrics.
- Do not attempt to repair the iron yourself. Always contact authorized service personnel.